

## Honeywell (HHP) 2020 / 4820 / 4820i Scanner Setup

The following guide is for configuring the Honeywell (HHP) 2020, 4820, and 4820i Cordless Barcode Scanners to function properly with **SerialMagic Professional** software. SerialMagic enables these scanners to work on the following platforms: Windows Mobile, BlackBerry, and PalmOS, Symbian OS9 phones, along with Windows PC and Mac OSX platforms.



### Scanner Setup

**Print** out the following barcodes (pgs. 1-2 of this document), and scan them in order. Once the scanner has been configured, see the section on setting up SerialMagic.

These codes can also be found in the [HHP 2020 / 4820 / 4820i Configuration Guide](#).



Standard Product Default Settings:  
All Application Groups



Non-Base BT Connection



BT Connection - PDA/Mobility Systems Device



Bluetooth PIN

Scan the “0” barcode (below) 4 times - 0000



0



Save



Add CR Suffix  
All Symbologies

Scanner Configuration Complete! Your scanner is ready to pair and connect to your computer or mobile device. Just make sure the SerialMagic Professional software is set for “Device Type” of “Other.” Once connected, simply place the cursor in the target location and scan a barcode!