

Essential Mode Switching Barcodes

These control barcodes are valid ONLY to LaserChamp scanners running firmware version x.36.xx. These scanners would have been purchased after August 01, 2006.

Switch to Legacy Mode



Switch to Plus Mode (Plus Mode and Plus Protocol)



Note: Barcodes can only be read from opposite modes. Ex. Switch to Legacy barcode can only be scanned if scanner is in PLUS mode. And vice-versa...